



Bluefin Led Underwater lights.

BluefinLed switch Installation manual.

Thank you for choosing Bluefin LED underwater lights, our products have been designed and tested rigorously to ensure the optimum performance and longevity.

Please ensure that your product is installed as per our instructions below, failure to do so may invalidate your warranty.

This switch is to be used with Bluefin Led's range of underwater lights to complete your installation and control your lights.

Please follow the wiring schematic below to install the switch correctly, all wires are labelled with the corresponding connections.

Please ensure that all connections are water proof.

The cut out for the switch is 17mm x 51mm, please use sealant to seal the unit when installed.

Wire descriptions:

Small loop between Pins 7 & 8 then tail on Pin 7 (18AWG in Black 85 Deg C PVC) 500mm length.

Label:- Gnd/Neg.


Pin 6 pos Red 18 AWG 500mm tail.

Label:- +Ve dash lights.

Power connections for lights onto Pins 2 & 3, 2000mm (2 meter) tails.

Label Pin 2:- +Ve In.

Label Pin 3:- +Ve Lights.



Warranty:

Your product has a 2 year limited warranty for defects.

For any warranty issues please contact your point of sale retailer or go to www.bluefinled.com for further advice.

Bluefin LED

Cottage Farm, Cottage Lane,
Norton Juxta Twycross, Atherstone. CV9 3QH

Sales - Tel: 07950 909048

Service - Tel: 01827 880450

Administration - Tel: 01827 880450

Email: simon.steadman@bluefinled.com

Email: mark.branson@bluefinled.com

Email: samantha.barrie@bluefinled.com

Registered Address: Square Rig Limited, t/a Bluefin Led, Cottage Farm, Cottage Lane, Norton Juxta Twycross, Atherstone, CV9 3QH
Company Registration Number: 08871451 **VAT Number:** 179 2690 64

